

**WPT WINDSCREEN REPAIR CUSTOM KIT P/N WP5201 CONTAINS:**

1 EA	5006	WPT REPAIR RESIN 3,0 ml
1 EA	5007	WPT FINISH RESIN 3,0 ml
1 EA	5011	SYRINGE WITH INJECTION NEEDLE 50 mm
1 EA	5050	DRILL BUR 1,0 mm
1 EA	5062	PACK OF 25 CURING FILMS 7 x 3 cm
1 EA	5063	PACK OF 5 SINGLE EDGE RAZOR BLADES
1 EA	5211	REPAIR JIG (LEVER TYPE)
1 EA	5217	PLASTIC POLISH, 200 ml
1 EA	5220	PROBE
1 EA	5221	SEALANT FOR RUBBER
1 EA	5224	INSPECTION MIRROR WITH SUCTION CAP
2 EA	5225	MANUAL INJECTOR
1 EA	5230	UV CURING LAMP, 220 VOLT
1 EA	5240	DRILL, 220 VOLT
1 EA	5297	INSTRUCTION MANUAL
1 EA	5295	CARRYING CASE WITH FOAM INSERT

01.03.2009 / JT